

Luftdruck Setup 34er



Maximaler Luftdruck: 110 PSI (7.58 Bar)

34 mm Float 26"/27.5" und 140mm/150mm 29" Richtlinien zum einstellen des Luftdruckes (in PSI)		
Fahrgewicht - kg	26" 160 / 140mm	27.5" 160 150mm
< 57	45	40
57 - 61	50	45
61 - 66	55	50
66 - 70	65	60
70 - 77	70	65
77 - 84	75	70
84 - 91	80	80
91 - 98	90	90
98 - 104	100	100
104 - 113	110	110

Einstellen der Nachgiebigkeit		
Federweg	XC/Race HART	Freeride WEICH
140 mm	21 mm	35 mm
160 mm	24 mm	40 mm

34 mm Talas 26"/27.5" und 140mm/150mm 29" Richtlinien zum einstellen des Luftdruckes (in PSI)		
Fahrgewicht - kg	26" 160 / 140mm	27.5" 160 150mm
< 57	45	40
57 - 61	50	45
61 - 66	55	50
66 - 70	65	60
70 - 77	70	65
77 - 84	75	70
84 - 91	80	80
91 - 98	90	90
98 - 104	100	100
104 - 113	110	110

Einstellen der Nachgiebigkeit		
Federweg	XC/Race HART	Freeride WEICH
140 mm	21 mm	35 mm
160 mm	24 mm	60 mm

Infos in english unter: [www.ridefox.com / help](http://www.ridefox.com/help)